

7. If brake lights operate with foot off pedal, remove a single washer and test again.
8. Remove further washers, one at a time until lights operate correctly.
9. Remove a further 2 washers.
10. Hold switch in position and fit brass nut finger tight.
11. Since access required to tighten nut is limited, the following procedure is recommended.
 - Remove brake pedal to servo push rod clip and clevis pin.
 - Remove circlip which locates brake pedal in position on cross shaft, slide pedal to one side to provide access to pedal switch.
 - Using a suitable 14 mm combination spanner, tighten switch securing nut.
 - Slide brake pedal back into position on cross shaft ensuring that bushes are correctly located, refit circlip to cross shaft.
 - Reconnect servo push rod clevis pin and clip (ensure clip is fitted the correct way round, i.e. hook end outer).

BEFORE RETURNING VEHICLE TO CUSTOMER, ENSURE BRAKE PEDAL OPERATES FREELY AND THAT BRAKE LIGHT IS OPERATING CORRECTLY.

PARTS INFORMATION:

**XKB 10003 - Switch - Stop Lamp
DJP 5822 - Washer (7 off required)**

WARRANTY CLAIMS:

Use Complaint Code: 7N1U

Use S.R.O.: 70.35.88/28

Time allowance: 0.40 Hrs