Mr/Mrs/Ms	Model					Reg No					
Invoice/Job No	Odometer reading				VIN						
Service type	FS	А	В	Α	В	Α	В	Α	В		\neg
Months/,000km	3/5	12/25	24/50	36/75	48/100	60/125	72/150	84/175	96/200		
											_



Adjust/Lubricate/Replace - Labour cost including in scheduled time except items marked*	MGF ECD3 only - Vin no. RD522573 on
Check - After the checking procedure, cleaning, adjusting, repairing or replacing is subject to extra labour and	iu materiai cost
	MAINTENANCE CHECK SHEE
PRELIMINARY	
Before commencing work, check for any outstanding service actions	
FS FIRST SERVICE	28 Replace camshaft drive belt - Every 100,000 km
Check suspension height and adjust if necessary - record details	29 Replace rear camshaft drive belt VVC - Every 100,000 km
LHFRHRLHR	30 Replace manual gearbox oil - Every 175,000 km
A B MAIN SERVICE - (VEHICLE INTERIOR)	31 Replace automatic gearbox oil
Adjust handbrake - First 25,000 km only	32 Check automatic gearbox level
Check handbrake operation	33 Check battery connections and antifreeze
Check seatbelt and airbag module covers - 36 months and then every 12 months	34 Check brake, clutch & gearbox fluid levels
Lubricate strikers, latches (use Rover lock grease) door hinges and door checks	35 Check pressure sensing hoses and vacuum pipes
Lubricate hood pivot points (remover hard top if necessary)	36 Check cooling system hoses and connections for signs of leakage and condition
Replace alarm handset batteries	37 Check fuel & clutch pipes and hoses for signs of leakage and condition
	38 Check condition of crankcase vent hoses & valves where fitted
MAIN SERVICE - (VEHICLE EXTERIOR)	39 Check air conditioning system, hoses and sight glass
Annual corrosion/cosmetic inspection - Using annual corrosion inspection sheet Check front brake linings, disc, calibers, hoses and pipes	40 Check auxiliary drive belts tension and condition
	41 Replace air cleaner element
Check rear brake linings, disc, calipers, hoses and pipes	42 Replace fuel filter - Every 100,000 km
2 Grease suspension pivots 3 Check suspension and steering for signs of leaking or wear	43 Replace spark plugs - Every 100,000 km
	44 Replace brake fluid - Every 24 months regardless of mileage* (indicate replacement
	service record)
LHF RHF RHR LHR	45 Check exhaust system and heat shields
5 Check wheel bearings, drive shafts and gaiters 6 Check lamps, horns, and system warning indicators	15 YEAR REPLACEMENT - AIRBAGS
	46 Replace airbag module(s)*
	47 Replace airbag rotary coupler* - When driver only airbag fitted
	AFTER EACH MAIN SERVICE
9 Remover front road wheels 0 Remove rear road wheels	48 Check oxygen sensor operation - at 36 months and then very 12 months
1 Check road wheels	49 Check CO at tailpipe - at 36 months and then every 12 months. (Record CO%)
2 Check tyre for damage and tread depth including spare (mm)	50 Carry out road test, check for the correct function of all vehicle systems
Check tyre pressures and adjust if necessary, including spare (bar) LHF RHF RHR LHR Spare	
	The maintenance items listed are those recommended for vehicles operating under normal driving, road ar
MAIN SERVICE - (ENGINE BAY)	climatic conditions. More frequent attention may be necessary if the vehicle is subject to stop/start operati extremes of temperature, dusty conditions or frequent towing of trailers.
4 Remove engine service hatch	extremes of temperature, dusty conditions or frequent towing of trailers.
Remove engine access cover - Every 100,000 km	Service check completed, cosmetic/corrosion inspection check completed and service portfolio book stam
Replace engine oil and filter	
Replace antifreeze* - every 4 years XLC (OAT)	
	Name Signature Date

GLOSSARY

FIRST SERVICE

= The first service required after sale of vehicle. This service is only

applicable to certain models as indicated by the maintenance check sheet.

MAIN SERVICE

= The main service is applicable to all vehicles. It is carried out at 12 months

or 25,000 km intervals, whichever occurs first.

Main Service 'A'

Is applicable at 12 months/25,000 km, 36 months/75,000 km, 60 months/125,000 km, 84 months/ 175,000 km and so on.

Main Service 'B'

Is applicable at 24 months/50,000 km, 48 months/100,000 km, 72 months/150,000, 96 months/200,000 km and so on. Some items do not need to be carried out at every main service and these items are identified by an indicator in the tick box e.g. 100k. (This indicates that this item is only applicable every 60 months/100,000 km)

For full details regarding the operations contained in this maintenance check sheet, please refer to the workshop manual.