Mr/Mrs/Ms						Model					Reg No	Reg No			
Invoice/Job No						0	dometer re	ading			VIN				
Service type Months/,000km		FS 3/5	A 12/20	B 24/40	A 36/60	B 48/80	A 60/100	B 72/120	A 84/140	B 96/160					



Adjust/Lubricate/Replace - Labour cost including in scheduled time except items marked*

Check - After the checking procedure, cleaning, adjusting, repairing or replacing is subject to extra labour and	material cost Pre ECD3 only - pre VIN no. RD522572
	MAINTENANCE CHECK SHEET
PRELIMINARY	
Before commencing work, check for any outstanding service actions	
	28 Replace antifreeze* - Every 2 years AFC, every 4 years XLC (OAT)
FS FIRST SERVICE 2 5k Replace engine oil and filter - First 5000 kilometres only	29 Replace camshaft drive belt - Every 100,000 km
	30 Replace rear camshaft drive belt VVC - Every 100,000 km
Check suspension height and adjust if necessary - record details	31 Replace manual gearbox oil - Every 160,000 km
LHF RHF RHR LHR	32 Replace automatic gearbox oil
A B MAIN SERVICE - (VEHICLE INTERIOR)	33 Check automatic gearbox level
Adjust handbrake - First 20,000 kilometres only	34 Check battery connections and antifreeze
5 Check handbrake operation	
6 Check seatbelt and airbag module covers - 36 months and then every 12 months	
7 Lubricate strikers, latches (use Rover lock grease) door hinges and door checks	
B Lubricate hood pivot points (remover hard top if necessary)	
Replace alarm handset batteries	
MAIN SERVICE - (VEHICLE EXTERIOR)	
Annual corrosion/cosmetic inspection - Using annual corrosion inspection sheet	
11 Check front brake linings, disc, calipers, hoses and pipes	41 Check auxiliary drive belts tension and condition 42 Replace air cleaner element
12 Check rear brake linings, disc, calipers, hoses and pipes	
13 Grease suspension pivots	
14 Check suspension and steering for signs of leaking or wear	44 Replace spark plugs - Every 100,000 km 45 Replace brake fluid - Every 24 months regardless of mileage* (indicate replacement on
15 Check suspension height and adjust if necessary - record details	45 Replace brake fluid - Every 24 months regardless of mileage* (indicate replacement on service record)
LHF RHF RHR LHR	46 Check exhaust system and heat shields
6 Check wheel bearings, drive shafts and gaiters	10 YEAR REPLACEMENT - AIRBAGS
Check lamps, horns, and system warning indicators	47 Replace airbag module(s)*
18 Check screen wipers and washers	48 Replace airbag rotary coupler* - When driver only airbag fitted
19 Check front screen number plates and V.I.N 36 months and then every 12 months	AFTER EACH MAIN SERVICE
20 Remover front road wheels	49 Check oxygen sensor operation - at 36 months and then very 12 months
21 Remove rear road wheels	50 Check CO at tailpipe - at 36 months and then every 12 months. (Record CO%)
22 Check road wheels	51 Carry out road test, check for the correct function of all vehicle systems
23 Check tyre for damage and tread depth including spare (mm)	31 Carry out load test, check for the correct function of all vehicle systems
LHF RHF RHR LHR Spare	
24 Check tyre pressures and adjust if necessary, including spare (bar)	The maintenance items listed are those recommended for vehicles operating under normal driving, road and
LHF RHF RHR LHR Spare	climatic conditions. More frequent attention may be necessary if the vehicle is subject to stop/start operation,
MAIN SERVICE - (ENGINE BAY)	extremes of temperature, dusty conditions or frequent towing of trailers.
25 Remove engine service hatch	Service check completed, cosmetic/corrosion inspection check completed and service portfolio book stamped.
Remove engine access cover - Every 100,000 km	
27 Replace engine oil and filter	
	Name Signature Date
77/01	DOL 0307ENV/A

07/01

GLOSSARY

FIRST SERVICE

=The first service required after sale of vehicle. This service is only applicable to certain models as indicated by the maintenance check sheet.

MAIN SERVICE

= The main service is applicable to all vehicles. It is carried out at 12 months or 20,000 km intervals, whichever occurs first.

Main Service 'A'

Is applicable at 12 months/20,000 km, 36 months/60,000 km, 60 months/100,000 km, 84 months/ 140,000 km and so on.

Main Service 'B'

is applicable at 24 months/40,000 km, 48 months/80,000 km, 72 months/120,000, 96 months/160,000 km and so on. Some items do not need to be carried out at every main service and these items are identified by an indicator in the tick box e.g.100k. (This indicates that this item is only applicable every 60 months/ 100,000 km)

For full details regarding the operations contained in this maintenance check sheet, please refer to the workshop manual.